

Touch Panel Device driver setting manual

For openSUSE 11.4 12.x 13.x 42.x 15.x

Prepare to Install

openSUSE 15.x:

KDE :

The touch driver not support Plasma(Wayland) and Plasma(full Wayland).

GENOME:

1. You need to disable wayland by setting WaylandEnable=false

in /etc/gdm/custom.conf or /etc/gdm3/custom.conf.

2. reboot

3. Install touch driver

Multiple display configuration

openSUSE in KDE

Set your display mode as desired using

System Settings->Display and Monitor -> Apply

Installation

1. Open terminal
2. Run the following commands to install the driver.

```
# su
```

```
# sh setup.sh
```

```
# reboot
```

Uninstallation

1. Open terminal
2. Run the following commands to uninstall the driver.

```
# su
```

```
# sh remove.sh
```

Touch Utility

Run touch utility method 1:

1. Clicking Launch Menu.
2. Type "touchtool" in the search box to search touch utility.
3. click on touchtool.

Run touch utility method 2

1. Open terminal
2. Run the following commands to start touch utility.

```
# Touchpack
```